



Pack 01 BUILD INSTRUCTIONS

STAGE 01: REAR LEFT WHEEL, HOSE, & NAME PLATE

STAGE 02: REAR PANEL AND FRONT RIGHT CAB DOOR

STAGE 03: FRONT GRILLE & REAR LEFT CAB DOOR

STAGE 04: FRONT BUMPER, AIR HORN, SPEAKER, & SEAT STAGE 05: COMPONENTS FOR THE CAB ROOF

STAGE 06: ASSEMBLING THE PLATFORM AND REAR AXLE

STAGE 07: LEFT-HAND SIDE STORAGE COMPARTMENT

STAGE 08: HANDY SCREW IDENTIFIER



Advice from the experts

Please keep ALL unused screws as they will be required in a later stage.

Please make sure you don't mix up the screws. They look quite similar, but the threads do vary slightly. Using the wrong screws may damage the parts.

When securing parts together using multiple screws, fit each screw loosely to ensure all the parts are correctly aligned before gently tightening them firmly, but not overtight, in the order in which you placed them.

The screwdriver can be magnetized by stroking it with a magnet (fridge magnet, etc.) enabling it to hold the screws and make assembly easier.

If a screw is tight going into a metal part, do not force it as you may shear the head off. Remove it and put a tiny smear of Vaseline, soap or light oil on the thread. That will lubricate it and make it easier to drive home.

During the course of this build, you will receive many pieces that you will assemble immediately – following the instructions in the corresponding stage – and other pieces that you should store safely to one side, for use in future assembly stages.

Left and Right! When building your fire truck, the left or right hand side refers to each side as you are sitting in the cab.

0

WARNING: Some parts are assembled using magnets. These magnets can cause serious injury if they are swallowed. Keep away from children. If you suspect a magnet has been swallowed, seek medical help straight away.

You'll start your first pack by assembling one of the rear wheels and the hose. The hose is rolled up for storage, but you may choose to leave it unwound if you have plans to create a live-rescue diorama!



Name
Rear tire x2
Ladder name plate
Inner wheel
Outer wheel
Hose pack
Hose nozzle
Hub cap
Hose connector
Ladder name plate
Rear tire Rear tire
Inner wheel Outer wheel
Hose pack Hub Cap Hose connector
Hose pack Hub Cap Hose connector
Hose pack Hub Cap Hose connector
Hose pack Hub Cap Hose connector

STEP 1



ASSEMBLING THE WHEEL

Push the inner wheel into one of the rear tires so that the tire rim tucks snugly around the groove on the wheel. If the tire is very tight, try soaking it in a hot water bath for one minute.





Push the outer wheel into the remaining tire and tuck the tire rim into the groove around the wheel.







FIX THE INNER AND OUTER WHEELS TOGETHER

Apply a drop of glue to the flat surface of the inner wheel as shown.

Take the outer wheel and align the four fixing pins with the holes on the inner wheel before pushing the two wheels together. Press firmly.

The inner and outer wheels have been glued together.


STEP 2



ASSEMBLING THE HOSE PACK Snip any frayed ends off the free end of the hose.



Apply a little superglue to the rim of the nozzle



Gently open either free end of the hose and fit it over the nozzle. Press firmly until it adheres.



Pinch the other end of the hose to fold it in half. This is going to fit inside the round opening of the connector.



Apply a drop of superglue inside the opening of the connector.



Push the end of the hose into the connector.



The connector is now fitted. You may choose to leave the hose unravelled...



... or wind it up, ready for storage in one of the tool compartments. Wind tightly around the connector until just a short length remains.



Apply a drop of superglue just before the end to stop the hose unravelling.



Hosepack complete.




You'll now start to assemble the fire truck rear panel and front right cab door.




Name			
Outer door panel			
Inner door panel			
Fire truck rear panel			
Inner cab panel			
Outer door handle			
Window winder			
Tow hooks x2			
Gear			
buter door panel	Inner door panel	Fire truck rear	
	Inner cab panel	Cear	

AGORAMODELS






FIXING THE TOW HOOKS Apply a little superglue to the tab on one of the two tow hooks.



Push the tab into the slot in the fire truck rear panel.



The left tow hook is now fitted



Repeat on the right side to fit the right tow hook.



Both tow hooks are now fitted to the rear panel.


STEP 2





ASSEMBLING THE DOOR

Push the handle into the hole in the inner door panel. Press firmly until you feel it click into place.






Check that you have the gear the correct way up – the flatest side faces up. Push it onto the square peg on the inside of the inner door panel.



The gear has been correctly fitted.




Apply a drop of superglue to each of the three peg holes and the tiny pin in the top right hand corner, as indicated (circled).




Align the three peg holes on the inner door panel with the three pegs of the inner side of the outer door panel before pressing the parts firmly together.



The inner door panel has been fixed to the outer door panel.



Take the inner cab panel and note that there are four fixing pins. It might be easier if you test fit the parts, then glue the raised areas that will sit underneath the hinge.



Align the four holes on the door hinge with the four pins on the inner cab panel. Check that the raised screw hole (circled in red above) is positioned centrally in the corresponding hole in the hinge.



Firmly press the hinge into place.



Apply a drop of superglue to the recess for the door handle before pressing the handle into position. This is a D-shaped fitting to ensure the correct fit.



The handle has now been fitted.



In this next stage, you'll assemble the Seagrave logo on the front grille, and the rear left cab door.



STAGE 03 PARTS LIST Name Outer door panel Inner door panel Inner cab panel Front grille Seagrave logo Window winder Rear grille Gear Outer door handle Outer door panel Inner door panel Inner cab panel υ. STOP Front grille Window winder eadrave lodd -IIIImIIII


Gear

Outer door handl

*


Rear grille





ASSEMBLING THE GRILLE


Apply a few tiny drops of superglue to the back of the Seagrave logo, then attach it to the front grille.






Align the notches on the side of the rear grille with the clips on the front grille. Note: the notches are different sizes to ensure the correct fit.





ASSEMBLING THE DOOR

Push the handle into the hole in the inner door panel. Press firmly until you feel it click into place.






Check that you have the gear the correct way up – the flatest side faces up. Push it onto the square peg on the inside of the inner door panel.




Apply a drop of superglue to each of the three peg holes as indicated (arrows).



Align the three peg holes on the inner door panel with the three pegs of the inner side of the outer door panel.



The inner door panel has been fixed to the outer door panel.



Take the inner cab panel and glue the raised areas that will sit underneath the hinge. It might be easier if you test fit the parts before gluing (also see pictures 9 & 10).



Align the four holes on the door hinge with the three pins and raised hole on the inner cab panel.



Firmly press the hinge into place.





Apply a drop of superglue to the recess for the door handle before pressing the handle into position. This is a D-shaped fitting to ensure the correct fit.




Now you'll fix the speaker and air horn to the front bumper of your fire truck, and assemble a seat.



Name		
Front bumper		
Seat		
Seat support		
Speaker		
Air horn		
LED		
	Front bumper	Seat
) (main: 16 (16-	
	· · · · · · ·	
		All port of the second s
	Speaker Air horn	
	ajitatan 🖌 🖌	
		Seat support
		Seat support
	IED	Seat support
	LED	Seat support
		Seat support
The LED will be used		Seat support


AGORAMODELS






FITTING THE AIR HORN

Push the air horn into the corresponding hole on the front bumper. Press firmly to fit.




FITTING THE SPEAKER

Apply a drop of superglue to the edges of the rectangular recess on the bumper.



Place the speaker over the recess and press until it adheres.



The air horn and speaker are now assembled on the bumper.

STEP 2




ASSEMBLING THE SEAT Apply a little superglue to the underside of the seat, avoiding the two rectanglular tabs.



Take the seat support and align it with the seat as shown. Check you have the seat support in the correct orientation with the vertical post aligned with the back of the seat.



Firmly press the two parts together.




In this next stage you'll start to assemble the cab roof, adding a variety of components, including the left-hand side condenser and antenna.




Name	
Condenser	
Condenser grille f	frame
Condenser grille	
Cab roof	
Roof component	С
Radio antenna Roof component	d
	u
Antenna part a Antenna part b	
Antenna part b	
Condenser Condenser grille frame Condenser grille frame Condenser grille	Cab roof Rof component c Ratio antenna Rof component d Rof






ASSEMBLING THE ANTENNA Take antenna part a and antenna part b, aligning them as shown before pushing firmly together.




Align the assembled antenna with the hole in the cab roof as indicated and push firmly to fit.

STEP 2




ASSEMBLING THE CONDENSER

Take the condenser grille frame and align the two projecting pegs with the two corresponding holes on the condenser. Push the pegs firmly into the holes to fit.




Apply a drop of superglue to the ledge around the condenser grille frame.




Carefully lay the condenser grille on the ledge.



The condenser grille has now been glued in place.




Push the two pegs on the underside of the condenser assembly into the corresponding holes in the cab roof. Note: the pegs and holes are different sizes to determine the correct fit.



The left-hand condenser unit has now been fixed to the cab roof.


STEP 3




FITTING THE RADIO ANTENNA

Take the left-hand radio antenna and note that the two pegs are different sizes. Determine the correct orientation by matching the pegs to the holes before pushing into place.


STEP 4





INSTALLING THE LED

Install the LED from stage 04 by feeding the cable through the opening in the roof before pushing the mounting firmly into place.




Next, you'll move on to the platform, assembling the four sides & adding some lights and handles. Then you will start to assemble the axle.



Name	
Rear ax	le
Drivesh	aft
Platforr	n right side
Platforr	n back
Platforr	n front light lenses
Platforr	n left side
Platforr	n front
Axle sp	ings
Platforr	n front lights
Rear pla	atform light
Type A	Screws x6
Type L S	Screws x2
	Screws x4
Platforr	n handles x2
R	
	Platform front lights

Platform handles x2






ASSEMBLING THE PLATFORM

Take the platform front and platform right side. Fit the screw sockets on the platform right side over the corresponding sockets on the platform front.




Fix in place with 2 x TYPE A screws.



Take the platform left side and fit the screw sockets over the corresponding sockets on the platform front.



Fix in place with 2 x TYPE A screws.




Take the platform back and fit the four screw holes over the four corresponding screw sockets on the platform sides.



Fix in place with 4 x TYPE C screws.


SEQUENCE











ATTACHING THE SINGLE PLATFORM LIGHT

Test fit the single light by pushing the pin on the back into the corresponding D-shaped hole on the platform back. You may need to trim the flash to fit. Once you are happy with the fit, apply a tiny drop of superglue and push into place.

STEP 3




ATTACHING THE PLATFORM FRONT LIGHTS

Cut three lenses off the sprues and fit them into the corresponding mounts on the platform front lights. Apply a drop of PVA glue if necessary.



Three lenses have been fitted to the platform front lights.



push it into the correspnding hole on the platform front. Apply a little

4 Identify the T-shaped fixing tab for the platform front lights and



STEP 4


superglue if necessary.





ATTACHING THE PLATFORM HANDLES

Take one of the platform handles and identify the two fixing points on the rear of the platform. Apply a little superglue to the two pins on the handle, then push into place.





Fix the second platform handle to the opposite side on the rear of the platform in the same way.

STEP 5



ASSEMBLING THE AXLE, DRIVESHAFT AND WHEEL

Take the driveshaft and identify the end with a screw hole. Align with the corresponding screw hole on the axle. Note: the post on the driveshaft should point upwards (see the Stage Complete photo on page 38).



Fix in place with a TYPE A screw.



Take the wheel from stage 01 and push it onto the rear right axle post as shown. Check you have placed it in the correct orientation.



Fix in place with a TYPE L screw.



Take the hubcap from stage 01 and push it over the screw fixed in picture 4.



The wheel has now been fixed to the axle.



Place the four axle springs on the axle posts as shown, or keep them in a safe place until you start the next stage.




In stage 7, you'll assemble one of the fire truck storage compartments, used to house vital rescue equipment.




Left-hand door front Left-hand door back			
Compartment inner			
Shelf top			
Right-hand door front			
Right-hand door back			
Magnet			
Shelf bottom			
		Compartment inner	
Left-hand door front	Left-hand door back		
°L	0		
	and the second se		
1	1- 0		
2			
		Shelf top	
		Sherr top	
Right-hand door front	Right-hand door back	Magnet	
		0	
	200		2
0		Shalf battern	
		Shelf bottom	

STEP 1



ASSEMBLING THE SHELF

Take the shelf bottom and position the magnet between the two tabs as shown in picture 2.



Test fit the shelf top to the shelf bottom and check you have the correct orientation, with the two holes as shown in picture 5. Once you're happy, apply a drop of glue to the two pins on the shelf top.

Align the pins with the corresponding holes in Push the parts together until the glue adheres. the shelf bottom.

STEP 2




ASSEMBLING THE LEFT-HAND DOOR

Take the left-hand door front and left-hand door back. Test fit the parts, noting that the peg and hole fixings are different sizes to ensure the correct fit. Note that both the door front and back are engraved with L3-1 for easy identification.



Apply a little glue to the two peg holes on the door back.



Fix the door back and door front together.




This shows the doors correctly assembled from the front and back views.

STEP 3






Take the right-hand door front and right-hand door back. Test fit the parts, noting that the peg and hole fixings are different sizes to ensure the correct fit. Note that both the door front and back are engraved with L3-2 for easy identification.




Apply a little glue to the two peg holes on the door back.






Fix the door back and door front together.

STEP 4




FIXING THE SHELF AND DOORS TO THE STORAGE COMPARTMENT INNER


Take the compartment inner and shelf. Ensure that the holes on the shelf are facing upwards before installing it onto the brackets on each side of the compartment inner. Do not glue as the shelf will slide in and out to store equipment at a later stage.




Apply a drop of glue to the recess on the left-hand side of the compartment inner.



Align the peg holes with the pegs and fix the left-hand door in place.



Apply a little more glue to the recess on the right hand side of the compartment inner.



Press firmly to fix the right-hand door in place.



Both doors have been fixed to the storage compartment.



Stage 08: Handy Screw Identifier

Please keep any unused screws supplied throughout your build. This handy screw reference will help you determine which screws to use as you progress with your model.

